


# Edison Gem Phonograph



## EDISON GEM

<u>Number</u>	<u>Item</u>	<u>Price</u>
910	Starting Rod	\$ 7.50
1003	End Gate - Model B	20.00
1005	End Gate Washer	2.50
1009	Carriage Rod	5.00
1011	Carriage - Model B Only	50.00
1012	Carriage - Model A Only	50.00
1013	Carriage Stop Pin	1.50
1016	Carriage Stop Pin Roller	3.00
1022	Reproducer Locking Screw	5.00
1023	Feed Nut and Bar	18.00
1024	Feed Nut	13.00
1025	Feed Nut Bar	5.00
1028	Feed Screw and Gear	45.00
1031	Feed Screw End Bearing	3.50
1034	Intermediate Gear	15.00
1036	Intermediate Gear Stud	1.50
1038	Mandrel - Model B	70.00
1039	Mandrel - Model D	70.00
1041	See 1038	--
1043	See 1038	--
1044	Mandrel Shaft	10.00
1045	Mandrel Shaft Collar - Model B	4.00
1046	Mandrel Shaft Collar - Model D	4.00
1048	Motor Side Frame - right	25.00
1049	Motor Side Frame - left	25.00
1051	Motor Frame Spacer	2.50
1052	Winding Shaft and Gear - Model B	40.00
1053	Winding Shaft and Gear - Model A	40.00
1054	See 1053	--
1055	See 1053	--
1057	Winding Shaft Spring	2.50
1060	Use Components	--
1061	Use Components	--
1062	Main Spring	42.00
1063	Main Spring Shaft	20.00
1065	Main Spring Shaft Pin	-- -
1066	First Gear and Ratchet	45.00

<b>Number</b>	<b>Item</b>	<b>Price</b>
1067	See # 1066	\$ --
1068	See # 1066	--
1070	Winding Ratchet Pawl	Inquire
1072	See # 1070	--
1073	Winding Ratchet Pawl Stud	.50
1074	Spring Retaining Washer	3.00
1075	Spring Stop Pin	.50
1079	Winding Gear Set Screw	1.50
1080	First Shaft with #1 & #2 Gear	38.00
1081	First Shaft	5.00
1082	#1 Gear	15.00
1085	Second Shaft with Collar and #3 Gear	30.00
1086	Second Shaft	5.00
1087	Second Shaft Collar	2.00
1088	#3 Gear	20.00
1094	Belt	Inquire
1095	Belt Tensioner Assembly	15.00
1096	See # 1095	--
1097	See # 1095	--
1112	Governor Shaft	35.00
1117	Starting Lever	15.00
1120	See # 1117	--
1121	Starting Rod Post	5.00
1122	Starting Lever Stud	5.00
1124	Starting Rod Spring	1.50
1125	Starting Rod Knob	Inquire
1126	Starting Rod Knob Set Screw	1.50
1127	Starting Rod Knob Retaining Pin	.25
1128	Starting Rod Knob Stop Pin	N/A
1131	Crank Knob	6.00
1133	Base Board Screw	2.00
1135	Winding Shaft Washer	1.00
1136	Washer Stop Pin	N/A
1138	Winding Ratchet Pawl for Wire Spring	Inquire
1139	Winding Ratchet Pawl Wire Spring	2.00
1140	Winding Ratchet Pawl Spring Stud	1.50
1186	Belt Tension Spring	2.00

<u>Number</u>	<u>Item</u>	<u>Price</u>
1196	Crank	\$ 30.00
1197	Winding Key (flat)	35.00
1198	Winding Key (slotted)	45.00
1228	#4 Gear	25.00
1239	Winding Gear	25.00
1245	#2 Gear	25.00
1472	Mandrel Shaft Nut	1.00
1563	Side Frame Spacer Screw	1.25
1608	#4 Gear Set Screw	2.00
1631	Governor End Bearing	3.50
1711	Feed Screw End Bearing Adjusting Screw	3.50
2053	Side Frame Screw	1.50
2059	See # 1053	--
2099	Lower Belt Pulley	28.50
2100	Pulley Set Screw	1.50
2108	See # 1095	--
2152	Lid Handle	15.00
2224	Carriage Lift Knob	7.50
2531	Carriage Reproducer securing thumb screw	5.00
2627	Governor Carrier Collar	inquire
2628	Governor Assembly	45.00
2639	Governor Carrier Set Screw	1.50
2782	Set Screw	1.50
2794	Governor Shaft End Bearing Set Screw	1.50
2798	End Gate Spring Screw	2.00
2801	Feed Nut Bar Screw	1.50
2817	Base Board Screw Washer	.25
2820	Governor Disc and Sleeve	15.00
2825	Governor Spring and Weight	7.00
2828	Governor Spring Screw and Washer (set of 6)	4.00
2877	Case Bumper ( rubber foot )	.60
3265	Case Cover	Inquire
3266	Oak Base	Inquire
3267	Case Cover Screw	11.00